Quick Reference Guide for the usage of the Sous-Vide Probe

Congratulations for having purchased the Sous-Vide option. This is a quick reference guide that will help you to use this option correctly.

- V Please be careful. The Sous-Vide Probe and the handle can be hot. Risk of burning!
- \checkmark The tip of the Sous-Vide Probe is sharp.

Connection to the device

- ✓ Unscrew the lid.
- \checkmark Be careful! Do not bend the connector pin.
- \checkmark Note the right angle plug and the connection socket.
- \checkmark Connect the right angle plug.
- \checkmark Screw the right angle plug tight.

The Sous Vide Probe is automatically controlled by the Sous Vide option!

Insertion into the product

Attention! Do not bend the Sous-Vide Probe!

1. Place the Sous Vide sealing pad at the thickest part of the product. The vacuum bag has to be free of fat and clean in order for the sealing pads to stick.





2. Stick the Sous Vide Probe through the sealing pad into the product. Place the tip of the probe in the middle.



- 3. Unplug the Sous Vide probe when finished and clean it with soap and place it safely in the accessory bag.
- 4. Screw the lid on top of the connection socket for dirt protection.

Connecting socket

Anti-rotation

1-Point sensor

Screw fastening

Two connecting

Handle

pins